



DARK ADVENTURE

DARK ADVENTURE

DARK ADVENTURE



815 Mittel Drive, Wood Dale, Illinois 60191
Telephone: (312) 595-1443, Telex: 6871385 KONAM UW, Fax: (312) 595-2973
For Technical Assistance Call Toll Free (800) 222-6181 (Outside Illinois)

DARK ADVENTURE™ is a registered trademark of Konami Inc. © 1987 Konami Inc.

 KONAMI® is a trademark of Konami Industry Co., Ltd.

DARK ADVENTURE: WIRING HARNESS

DARK ADVENTURE: SUB HARNESSES


		Solder Side		Parts Side	
WIRE COLOR KEY:					
BLACK		GND	A 1	GND	BLACK
BLACK		GND	B 2	GND	BLACK
RED		+5V DC	C 3	+5V DC	RED
RED		+5V DC	D 4	+5V DC	RED
ORANGE		+12V DC	E 5		
BROWN/YELLOW	COIN COUNTER 2	*KEY	F 6	+12V DC	ORANGE
			H 7	*KEY	
			J 8	COIN COUNTER 1	GREEN/GRAY
			K 9		
			L 10		
			M 11		
WHITE/GREEN	VIDEO GREEN		N 12	VIDEO RED	RED/WHITE
WHITE	VIDEO SYNC		P 13	VIDEO BLUE	BLUE/WHITE
			R 14	VIDEO GROUND	BLACK
			S 15		
VIOLET/WHITE	COIN 2		T 16	COIN 1	BLUE/BROWN
			U 17	MAP	PINK/YELLOW
BLUE/YELLOW	2P UP		V 18	1P UP	ORANGE/WHITE
VIOLET/YELLOW	2P DOWN		W 19	1P DOWN	BLACK/WHITE
ORANGE/GREEN	2P LEFT		X 20	1P LEFT	RED/GRAY
ORANGE/YELLOW	2P RIGHT		Y 21	1P RIGHT	GRAY/WHITE
BLACK/YELLOW	2P JUMP/START		Z 22	1P JUMP/START	PINK/WHITE
ORANGE/GRAY	2P ATTACK		a 23	1P ATTACK	GREEN/BROWN
BROWN/WHITE	2P DYNAMITE		b 24	1P DYNAMITE	RED/BROWN
			c 25		
			d 26		
BLACK	GND		e 27	GND	BLACK
BLACK	GND		f 28	GND	BLACK

(BASE COLOR/LINE COLOR)

CN3 3P CONTROLS (JST)	1	COIN 3	RED
	2		
	3	3P LEFT	WHITE/RED
	4	3P RIGHT	WHITE/YELLOW
	5	3P UP	WHITE/BLACK
	6	3P DOWN	WHITE/BLUE
	7	3P JUMP/START	WHITE/BROWN
	8	3P ATTACK	WHITE/ORANGE
	9	3P DYNAMITE	WHITE/GRAY
	10		
	11		
	12	COIN COUNTER 3	BLUE
	13		
	14		
	15	GROUND	BLACK
CN8 SPEAKER OUTPUT (JST)			
1	SPEAKER +	WHITE	
2	SPEAKER -	BLACK	
3	SPEAKER -	BLACK	
4	SPEAKER +	GRAY	

DARK ADVENTURE: AC FLOW CHART

1. GREEN/YELLOW
2. BLACK
3. RED
4. BLUE
5. BROWN
6. RED/BLACK
7. BLACK/WHITE
8. WHITE
9. GREEN
10. VIOLET
11. ORANGE



DIP SWITCH SETTINGS

DIP SWITCH NO. 1 SETTINGS

SW	1	2	3	4	COIN	CREDIT
•	OFF	OFF	OFF	OFF	1	1
	ON	OFF			1	2
	OFF	ON			1	3
	ON	ON			1	4
	OFF	OFF	ON	OFF	1	5
	ON	OFF			1	6
	OFF	ON			1	7
	ON	ON			2	1
	OFF	OFF	OFF	ON	2	3
	ON	OFF			2	5
	OFF	ON			3	1
	ON	ON			3	2
	OFF	OFF	ON	ON	3	4
	ON	OFF			4	1
	OFF	ON			4	3
	ON	ON			INVALID	

DIP SWITCH NO. 2 SETTINGS

THE NUMBER OF THE PLAYER'S LIFE

	1	2	NUMBER
•	OFF	OFF	2
	ON	OFF	3
	OFF	ON	5
	ON	ON	7

*The number of players life multiplied by the number of credit makes the number of players life for a play

DIFFICULTY OF THE GAME

SW	6	7	DIFFICULTY
•	OFF	OFF	EASY
	ON	OFF	NORMAL
	OFF	ON	DIFFICULT
	ON	ON	VERY DIFFICULT

SOUND

SW	8	SOUND
•	OFF	OFF
	ON	ON

DIP SWITCH 1

ON
OFF

•	•	•	•	•	•	•	•
1	2	3	4	5	6	7	8

SW5 through
SW8 are not used.

DIP SWITCH 2

ON
OFF

•	•	•
•	•	•

SW3 through
SW5 are not used.

DIP SWITCH NO. 3 SETTINGS

1. VIDEO SCREEN FLIP

SW	1	FLIP
•	OFF	NORMAL
	ON	UPSIDE DOWN

2. CHANGE OF MODE

SW	3	MODE
•	OFF	GAME MODE
	ON	CHECK MODE

DIP SWITCH 3

ON
OFF

•	•	•	•
1	2	3	4

SW2 and
SW4 are not used.

DARK ADVENTURE: WIRING DIAGRAM

